Your vehicle includes a variety of electronic features that can be personalized to your preferences. Programming these preferences requires specialized equipment and may be performed by an authorized Lexus dealership.
Some function settings are changed simultaneously with other functions being customized. Contact your Lexus dealer for further details.

Item	Function	Default setting	Customized setting
Smart access system with push-button start	Smart access system with push-button start	ON	OFF
	Operation signal (Emergency flashers)	ON	OFF
	Operation signal (Buzzer)	ON	OFF
Wireless remote control	Unlocking operation	Driver's door unlocked in 1-step, all doors unlocked in 2-steps	All doors unlocked in 1-step
	Time elapsed before automatic door lock function is activated if door is not opened after being unlocked	60 seconds	OFF
			30 seconds
			120 seconds
	Operation signal (Emergency flashers)	ON	OFF
	Operation signal (Buzzer)	ON	OFF
	Trunk unlocking function	ON	OFF
	Trunk unlocking operation	Push and hold	Push twice
			One short push
	Panic function	ON	OFF
	Buzzer sounds when pushing with any door not closed	ON	OFF

Item	Function	Default setting	Customized setting
Door lock	Unlocking using a key	Driver's door unlocked in 1-step, all doors unlocked in 2-steps	All doors unlocked in 1-step
	Speed-detecting automatic door lock function	OFF	ON
	Opening driver's door unlocks all doors	OFF	ON
	Shift the shift lever to "P" unlocks all doors.	ON	OFF
	Shift the shift lever to position other than "P" locks all doors	ON	OFF
Power windows	Linked door lock operation	ON	OFF
	Linked door key operation	Open and close	Open only
			Close only
	Wireless remote control linked operation	ON	OFF
	Linked entry function	ON	OFF

<table>
<tr><th>Item</th><th>Function</th><th>Default setting</th><th>Customized setting</th></tr>
<tr><td rowspan="7">Moon roof</td><td>Linked door lock operation</td><td>ON</td><td>OFF</td></tr>
<tr><td rowspan="2">Linked door key operation</td><td rowspan="2">Open and close</td><td>Open only</td></tr>
<tr><td>Close only</td></tr>
<tr><td>Linked operation of components when door key is used</td><td>Slide only</td><td>Tilt only</td></tr>
<tr><td>Wireless remote control linked operation</td><td>ON</td><td>OFF</td></tr>
<tr><td>Linked operation of components when wireless remote control used</td><td>Slide only</td><td>Tilt only</td></tr>
<tr><td>Linked entry function</td><td>ON</td><td>OFF</td></tr>
<tr><td rowspan="5">Automatic light control system</td><td>Light sensor sensitivity</td><td>Level 3</td><td>Levels 1 to 5</td></tr>
<tr><td rowspan="3">Time elapsed before headlights automatically turn off after doors are closed</td><td rowspan="3">30 seconds</td><td>0 seconds</td></tr>
<tr><td>60 seconds</td></tr>
<tr><td>90 seconds</td></tr>
<tr><td>Day time running light</td><td>ON</td><td>OFF*</td></tr>
<tr><td rowspan="3">Windshield wipers and washer</td><td>Switching operation when the vehicle is stationary</td><td>ON</td><td>OFF</td></tr>
<tr><td>Drip prevention function</td><td>ON</td><td>OFF</td></tr>
<tr><td>Time elapsed before the drip prevention function operates</td><td>Variable depending on the vehicle speed</td><td>3 seconds</td></tr>
</table>

*: Vehicles sold outside Canada

Item	Function	Default setting	Customized setting
Illumination	Time elapsed before lights turn off	15 seconds	7.5 seconds
			30 seconds
	Operation when the doors are unlocked	ON	OFF
	Operation after the "ENGINE START STOP" switch turned OFF	ON	OFF
	Front/rear personal lights turned on when a door is opened	Correspond-ing light only	All lights
			OFF
	Foot lights	ON	OFF
	Shift lever light	ON	OFF
	Outer foot light	ON	OFF
Rear sunshade	Time elapsed before the reverse operation feature acti-vates	0.7 seconds	0 seconds
			0.9 seconds
			1.2 seconds

Your Lexus dealer

Your Lexus dealer will provide quality maintenance and any other assistance you may require.

If there is not a Lexus dealer near you, please call the following number:

- **U.S. OWNERS**
  - In the U.S. mainland or Canada:
    Lexus Roadside Assistance
    1-800-25-LEXUS or 1-800-255-3987 (Toll-Free)
  - In Hawaii:
    Servco Automotive Roadside Assistance/Customer Services
    1-800-25-LEXUS or 1-800-255-3987 (Toll-Free)
- **CANADIAN OWNERS**
  - In Canada or the U.S. mainland:
    Lexus Roadside Assistance/Customer Service
    1-800-26-LEXUS or 1-800-265-3987 (Toll-Free)

Please access our **websites** for further information.

- The U.S. mainland: **www.lexus.com**
- Hawaii: **www.servcolexus.com**
- Canada: **www.lexus.ca**